

V1F 固件说明

- 一、请使用神牛固件升级软件 G3 打开该固件进行升级。G3 可在官网上下载。
- 二、版本号查看方法：开机后按 “MENU” 按键，进入 C.Fn 菜单。右上角显示 Ver x.x 为版本号。
- 三、版本说明：

版本	更新内容	日期
V1.3	兼容徕卡引闪器 XProIII 无线系统	2022-08-16
V1.2	1、增加 mode 按键锁住功能（长按 MODE 按键 2 秒） 2、替换字符，RX 替换 Slave。	2020-07-16
V1.1	1、改善热保护系统 2、调整 LED 控制方式 3、解决在机顶模式下曝光补偿（FEC）值翻倍问题	2019-08-17

注：详细规格请在官网（www.godox.com.cn）下载最新说明书。

V1F Firmware Release Note

1. Please update the firmware with Godox firmware update software G3. G3 can be downloaded on the official website.
2. How to check the version number: turn on the gear, and press the “MENU” button to enter the C. Fn menu. The top right-hand corner of the screen will show Ver x.x which is the version number.
3. Version Instructions:

Version	What's New	Date
V1.3	To add compatibility with Flash Trigger for Leica --- XProIII Wireless System	2022-08-16
V1.2	1.To add the lock function of the mode button (press the MODE button for 2 seconds) 2.To replace the display sign “Slave” with “RX”.	2020-07-16
V1.1	1. To improve heat protection system 2. To adjust the LED control mode 3. To solve the problem that the Exposure Compensation (FEC) Value doubles in on-camera mode	2019-08-17

Note: For more details, please download the newest instruction manual on the official website:
www.godox.com.