

X2T-P 宾得 发射器固件说明

- 一、请使用神牛固件升级软件 G3 打开该固件进行升级。G3 可在官网上下载。
- 二、版本号查看方法：发射器开机，按“MENU”按键进入菜单设置，在屏幕右上角显示固件版本号（如 1.1 版本：V1.1）。
- 三、版本说明：

版本	更新内容	日期
V1.3	1、修复 V1.2 固件升级后无法设置 CH 值的问题。	2022-08-02
V1.2	1、配合手机 APP 的更新。	2022-06-30
V1.1	1、修复设置为 APP 模式下，不发送修改过的值到接收端的问题。 2、恢复出厂设置时，重设蓝牙密码为初始值。	2020-07-20
V1.0	初始版本	

注：详细规格请在官网（www.godox.com.cn）下载最新说明书。

X2T-P Firmware Release Note

1. Please update the firmware with Godox firmware update software G3. G3 can be downloaded on the official website.
2. How to check the version: turn on the X2T-C, and press the "MENU" button to enter menu settings. The screen will display the firmware version (e.g. Version 1.1: V1.1) in the top right-hand corner.
3. Version Instructions:

Version	What's New	Date
V1.3	1. To solve the problem that the CH value cannot be set after the V1.2 firmware upgrade.	2022-08-02
V1.2	1. To match the update of Godox flash APP.	2022-06-30
V1.1	1. To solve the problem of not sending the modified value to the receiving end in APP mode. 2. When restoring the factory settings, the Bluetooth password is reset to the initial value ("000000").	2020-07-20
V1.0	The original version	

Note: For more details, please download the newest instruction manual on the official website:
www.godox.com.