

WMicS1_universality 升级说明书

- 1、电脑端打开固件升级软件 G3。
- 2、在关机状态下，按住“菜单”按键然后接上 USB 线，看到电脑端固件升级软件 G3 对话框显示“连接设备成功”便可松开“菜单”按键。
- 3、在固件升级软件 G3 上点击“打开文件”，选择对应的升级文件，然后点击“升级”，对话框显示“更新设备成功”便升级成功。
- 4、拔掉 USB 线后重新插上 USB 线，开机完成后短按“减”键到版本显示界面，查看版本确认升级是否成功。

注：第 3 步中的“对应的升级文件”

接收机：WMicS1_RX_universality_App_V2.00_21_3C1775.bin

GD-RD-322_universality Upgrade Instruction

1. Open the firmware upgrade software G3 on the computer.
2. Turn off the product, press and hold the "Menu" button and then connect the USB cable to the computer, release the "Menu" button when the dialog box of firmware upgrade software G3 displays "Connected".
3. Click "Open File" on the firmware upgrade software G3, select the corresponding upgrade file then click "Upgrade", the dialog box will display "Updated" after completion.
4. Pull out the USB cable and plug in again, turn on the product and short press the "minus" button to enter the version interface, then check the version to confirm whether it is successfully upgraded.

Note: "Corresponding upgrade file" in step 3

Receiver: WMicS1_universality_App_V2.00_21_3C1775.bin